


THE NETWORK INTERFACE CARD TECHNICAL GUIDE

GATEWAY COMMUNICATIONS, INC.
G/ETHERTWIST 8 ADAPTER

NIC Type	Ethernet
Transfer Rate	10Mbps
Data Bus	8-bit ISA
Topology	Linear Bus
	Star
Wiring Type	Shielded twisted pair
	Unshielded twisted pair
	AUI transceiver via DB-15 port
Boot ROM	Available



INTERRUPT REQUEST						
IRQ	JP2A	JP2B	JP2C	JP2D	JP2E	JP2F
i3	Open	Closed	Open	Open	Open	Open
2	Closed	Open	Open	Open	Open	Open
4	Open	Open	Closed	Open	Open	Open
5	Open	Open	Open	Closed	Open	Open
6	Open	Open	Open	Open	Closed	Open
7	Open	Open	Open	Open	Open	Closed

CABLE TYPE	
Type	JP4
iRG-58A/U 50ohm coaxial	Pins 1 & 2 Closed
AUI transceiver via DB-15 port	Pins 2 & 3 Closed

LINK INTEGRITY TEST	
Setting	JP5
iEnabled	Pins 1 & 2 Closed
Disabled	Pins 2 & 3 Closed
Note: Link Integrity is only used with 10Base-T wiring. When using an AUI transceiver, the test should be disabled.	


Continued on next page . . .

GATEWAY COMMUNICATIONS, INC. G/ETHERTWIST 8 ADAPTER

... continued from previous page

I/O BASE ADDRESS				
Address	SW1/1	SW1/2	SW1/3	SW1/4
i2A0-2BF	On	Off	On	On
280-29F	On	On	On	On
2C0-2DF	On	On	Off	On
2E0-2FF	On	Off	Off	On
300-31F	On	On	On	Off
320-33F	On	Off	On	Off
340-35F	On	On	Off	Off
360-37F	On	Off	Off	Off

BOOT ROM ADDRESS		
Address	SW1/5	SW1/6
iC000-CFFFFh	Off	Off
C0000-C3FFFh	On	On
C4000-C7FFFh	Off	On
C8000-CBFFFh	On	Off



DIAGNOSTIC LED(S)		
LED	Status	Condition
1	On	Card is sending random data (Jabbering)
1	Off	Card is configured correctly and is operating normally
2	On	Network connection is good ¹
2	Off	Card is not connected to network ¹
2	On	Link test is disabled ²
2	Blinking	Disabled the link test signal ³
3	Blinking	Data is being transmitted
3	Off	Data is not being transmitted
4	Blinking	Data is being received
4	Off	Data is not being received

Note 1 : Used when the Link Test signal is enabled (JP5)
 Note 2 : LED remains on when the Link Test signal is disabled (JP5)
 Note 3 : When the Link Test signal is enabled and the card is connected to a hub that does not use the Link Test signal, the user should disable the Link Test signal.

Continued on next page ...

GATEWAY COMMUNICATIONS, INC. G/ETHERTWIST 8 ADAPTER

... continued from previous page

FACTORY CONFIGURED SETTINGS - DO NOT ALTER	
Jumper	Setting
JP1	Unknown (Used for Channel configuration)
Note: Link Integrity is only used with 10Base-T wiring. When using an AUI transceiver, the test should be disabled.	
MISCELLANEOUS NOTES	
Different drivers must be used for the National & the Fujitsu chipset cards, they are not interchangeable. Fujitsu drivers may be used for either 8 or 16 bit Fujitsu cards, while the National chipset cards require a different driver for an 8 or 16 bit card.	