
ZENITH DATA SYSTEMS SQ-5550/5551

NIC Type Transfer Rate Ethernet 10Mbps Data Bus 16-bit ISA Topology Wiring Type Boot ROM Star

Shielded/Unshielded twisted pair

Available



DMA CHANNEL								
Channel	JP1A	JP1B	JP1C	JP1D	JP2A	JP2B	JP2C	JP2D
DMA3	Open	Open	Open	Closed	Open	Open	Open	Closed
íDMA5	Open	Open	Closed	Open	Open	Open	Closed	Open
DMA6	Open	Closed	Open	Open	Open	Closed	Open	Open
DMA7	Closed	Open	Open	Open	Closed	Open	Open	Open

INTERRUPT REQUEST						
IRQ	JP3A	JP3B	JP3C	JP3D	JP3E	JP3F
í3	Closed	Open	Open	Open	Open	Open
4	Open	Closed	Open	Open	Open	Open
5	Open	Open	Closed	Open	Open	Open
9	Open	Open	Open	Closed	Open	Open
10	Open	Open	Open	Open	Closed	Open
15	Open	Open	Open	Open	Open	Closed

	DATA I/O	O MODE					
Setting					JP4		
í8-bit mode	Pins 2 & 3 Closed						
16-bit mode				Pins 1 8	& 2 Clos	ed	
Note: Card must be installed in a 16-bit slot. This se		tting controls	the s	size of the	he data	bus used.	Memory
accesses always use 16-hit words							

Continued on next page . . .

ZENITH DATA SYSTEMS SQ-5550/5551

. . . continued from previous page

BOOT ROM				
Setting	JP5			
íDisabled	Open			
Enabled	Closed			

I/O BASE ADDRESS AND BOOT ROM ADDRESS					
Address	ROM Address	JP6	JP7		
í300h	C8000h	Closed	Closed		
320h	CC000h	Closed	Open		
340h	D0000h	Open	Closed		
360H	D4000h	Open	Open		



	DIAGNOSTIC LED(S)	
LED	Status	Condition
1	On	Data is being transmitted
1	Off	Data is not being transmitted
2	Bright	Data is being received
2	Dim	Link pulses are being received
2	Off	Data is not being received