


Chapter 5: Jumper Settings

MECER CORPORATION

B 3 6 3 T C

NIC Type	Ethernet
Transfer Rate	10Mbps
Data Bus	16-bit ISA
Topology	Linear Bus/Star
Wiring Type	Unshielded twisted pair
	AUI Transceiver via DB-15 port
	RG-58A/U 50ohm coaxial
Boot ROM	Available



BASE I/O ADDRESS SELECTION	
Address	JP2
300h	Pins 1 & 2, 3 & 4 closed
320h	Pins 1 & 2 closed
340h	Pins 3 & 4 closed
360h	all open

INTERRUPT SELECTION	
IRQ	JP1
3	Pins 15 & 16 closed
2/9	Pins 17 & 18 closed
4	Pins 13 & 14 closed
5	Pins 11 & 12 closed
6	Pins 9 & 10 closed
7	Pins 7 & 8 closed
10	Pins 5 & 6 closed
11	Pins 3 & 4 closed
12	Pins 1 & 2 closed

Continued next page...


THE NETWORK INTERFACE CARD TECHNICAL GUIDE
MECER CORPORATION
B 3 6 3 T C

... continued from previous page.

BOOT ROM CONFIGURATION	
Setting	JP3 (pins 7 & 8)
Disabled	Open
Enabled	Closed

ROM ADDRESS			
Address	JP3 (pins 1 & 2)	JP3 (pins 3 & 4)	JP3 (pins 5 & 6)
C0000h	Closed	Closed	Closed
C4000h	Open	Closed	Closed
C8000h	Closed	Open	Closed
CC000h	Open	Open	Closed
D0000h	Closed	Closed	Open
D4000h	Open	Closed	Open
D8000h	Closed	Open	Open
DC000h	Open	Open	Open

AT BUS WAIT STATE CONFIGURATION	
Setting	JP4
0 wait states	Closed
1 wait state	Open



DIAGNOSTIC LED(S)			
LED	Color	Status	Condition
LED1	Green	On	Network connection is good
LED1	Green	Off	Network connection is broken
LED2	Red	On	Data is being received
LED2	Red	Off	Data is not being received
LED3	Yellow	On	Data is being transmitted
LED3	Yellow	Off	Data is not being transmitted