
## **COMPAQ COMPUTER CORPORATION SOUND BOARD**

Card Type Chipset Controller Sound card Unidentified

Line in, Microphone in (2), volume control, stereo speaker out (2), mono speaker out, game/MIDI port, SCSI CD-ROM interface, CD-ROM audio out, I/O Options

PC speaker in

N/A **Maximum Dram** 



CONNECTIONS			
Purpos :	Location	Purpos ;	Location
Line in	J1	Molex-D 4 audio out	J6
Microphone in	J2	Right (mono) speaker out	J7
Stereo speaker out	J3	Audio I/O (see table below)	J8
Game/MIDI port	J4	PC Speaker in J9	
SCSI CD-ROM interface	J5	Volume control	R1

CONNECTOR J8			
Purpos :	Pin	Purpos ;	Pin
Microphone in ground	1	Right speaker out	5
Microphone in ground	2	Left speaker out	6
Microphone in	3	Right speaker return	7
Speaker out ground	4	Left speaker return	8

INTERNAL AUDIO AMPLIFIER CONFIGURATION		
Left an b Right ar p JP5		
í Enabled	Enabled	Pins 2 & 3, 5 & 6 closed
Disabled	Disabled	Pins 1 & 2, 4 & 5 closed

Continued on next page. . .

## COMPAQ COMPUTER CORPORATION SOUND BOARD

. . .continued from previous page

BASE I/O ADDRESS FOR MIDI PORT SELECTION		
Address JP4		
í 330h Pins 1 & 2 closed		
300h	Pins 1 & 2 open	

BASE I/O ADDRESS FOR SOUND CARD SELECTION		
Address	JP6	
í 220h	Pins 7 & 8, 9 & 10 closed	
240h	Pins 9 & 10 closed	
260h	Pins 7 & 8 closed	
280h	Pins 7 & 8, 9 & 10 open	

BASE I/O ADDRESS FOR SCSI INTERFACE SELECTION		
Address JP7		
í 340h Open		
140h	Closed	

INTERRUPT FOR SCSI INTERFACE SELECTION	
IRQ	JP3
9	Pins 1 & 2 closed
10	Pins 3 & 4 closed
í 11	Pins 5 & 6 closed
12	Pins 7 & 8 closed

INTERRUPT FOR SOUND CARD SELECTION	
IRQ JP4	
2	Pins 11 & 12, 13 & 14 closed
í 5	Pins 13 & 14 closerd
7	Pins 11 & 12 closed
10	Pins 11 & 12, 13 & 14 open

GAME PORT CONFIGURATION		
Port JP6		
í Enabled	Pins 5 & 6 closed	
Disabled	Pins 5 & 6 open	

8-BIT DMA CHANNEL FOR SOUND CARD SELECTION		
Channel JP4		
0	Pins 3 & 4, 5 & 6 closed	
ſ1	Pins 5 & 6 closed	
3	Pins 3 & 4 closed	

Continued on next page. . .

## COMPAQ COMPUTER CORPORATION SOUND CARD

. . .continued from previous page

16-BIT DMA CHANNEL FOR SOUND CARD SELECTION		
Channel JP4		
í 5	Pins 7 & 8, 9 & 10 closed	
6	Pins 9 & 10 closed	
7	Pins 7 & 8 closed	

DMA CHANNEL FOR SCSI INTERFACE SELECTION		
Chann I	JP1	JP2
í O	Pins 1 & 2 closed	Pins 1 & 2 closed
5	Pins 3 & 4 closed	Pins 3 & 4 closed
6	Pins 5 & 6 closed	Pins 5 & 6 closed
7	Pins 7 & 8 closed	Pins 7 & 8 closed