


# COMPUTER PERIPHERALS, INC.

## VIVA 14.4/FAX INTERNAL

<b>Modem Type</b>	Data (synchronous/asynchronous)/Fax
<b>Maximum Data Rate</b>	14.4Kbps
<b>Maximum Fax Rate</b>	14.4Kbps
<b>Data Bus</b>	8-bit ISA
<b>Fax Class</b>	Class I & II
<b>Data Modulation Protocol</b>	Bell 103A/212A
	ITU-T V.21, V.22, V.22bis, V.23, V.32, V.32bis
<b>Fax Modulation Protocol</b>	ITU-T V.17, V.27ter, V.29
<b>Error Correction/Compression</b>	MNP5, V.42, V.42bis



CONNECTIONS			
Purpos	Location	Purpos	Location
Line out	CN1	Line in	CN2

BASE I/O ADDRESS SELECTION				
Port	SW1/1	SW1/2	SW1/3	SW1/4
COM1: (3F8h)	On	Off	Off	Off
COM2: (2F8h)	Off	On	Off	Off
COM3: (3E8h)	Off	Off	On	Off
COM4: (2E8h)	Off	Off	Off	On

INTERRUPT SELECTION				
IRQ	JP1/A	JP1/B	JP1/C	JP1/D
2	Open	Open	Open	Closed
3	Closed	Open	Open	Open
4	Open	Closed	Open	Open
5	Open	Open	Closed	Open

Continued on next page . . .

## Proprietary AT Command Set

AUTO-RETRAIN	
<b>Type:</b>	Configuration
<b>Format:</b>	AT [cmds] %E <i>n</i> [cmds]
<b>Description:</b>	Selects auto-retrain mode
Command	Function
i %E0	Auto-retrain disabled
%E1	Auto-retrain enabled

BIT-MAPPED REGISTERS	
Register	Default
S14	138
S16	0
S21	4
S22	117
S23	183
S27	9
S28	0
S31	2
S40	105
S41	195
S80	Unidentified

BREAK SEND	
<b>Type:</b>	Configuration
<b>Format:</b>	AT [cmds] \B <i>n</i> [cmds]
<b>Default:</b>	Unidentified
<b>Range:</b>	Unidentified
<b>Unit:</b>	.1 second
<b>Description:</b>	Sends break to modem

COMPUTER PERIPHERALS, INC.  
VIVA 14.4/FAX INTERNAL

...continued from previous page

BREAK TYPE			
<b>Type:</b>		Configuration	
<b>Format:</b>		AT [cmds] \Kn [cmds]	
<b>Description:</b>		Configures action of break signal	
Command	Break from DTE	Modem receives \B	Break from remote modem
\K0	Enter command mode, do not send break to remote modem	Buffers cleared and break sent to remote modem	Buffers cleared and break sent to DTE
\K1	Buffers cleared and break sent to remote modem	Buffers cleared and break sent to remote modem	Buffers cleared and break sent to DTE
\K2	Enter command mode, do not send break to remote modem	Send break to remote modem immediately	Send break to DTE immediately
\K3	Send break to remote modem immediately	Send break to remote modem immediately	Send break to DTE immediately
\K4	Enter command mode, do not send break to remote modem	Send break to remote modem with transmitted data	Break sent with received data to the DTE
f \K5	Send break with transmitted data	Send break to remote modem with transmitted data	Break sent with received data to the DTE

COMPRESSION	
<b>Type:</b> Configuration	
<b>Format:</b> AT [cmds] %Cn [cmds]	
<b>Description:</b> Selects data compression	
Command	Function
%C0	Data compression disabled
%C1	MNP5 enabled
%C2	V.42bis enabled
f %C3	MNP5 and V.42bis enabled

CONNECT MODE	
<b>Type:</b> Configuration	
<b>Format:</b> AT [cmds] \Nn [cmds]	
<b>Description:</b> Sets connect mode	
Command	Function
\N0	Normal mode enabled
\N1	Direct mode enabled
\N2	Reliable mode enabled
f \N3	Auto-reliable mode enabled
\N4	LAP-M mode only enabled
\N5	MNP mode only enabled

Continued on next page . . .

COMPUTER PERIPHERALS, INC.  
VIVA 14.4/FAX INTERNAL

...continued from previous page

DISPLAY CURRENT COMMAND STATUS	
<b>Type:</b>	Immediate
<b>Format:</b>	AT [cmds] \S [cmds]
<b>Description:</b>	Displays current setting of modem commands

DISPLAY STORED NUMBERS	
<b>Type:</b>	Immediate
<b>Format:</b>	AT [cmds] \F [cmds]
<b>Description:</b>	Displays all stored phone numbers

FAX TRANSMIT LEVEL	
<b>Type:</b>	Register
<b>Format:</b>	AT [cmds] S92= <i>n</i> [cmds]
<b>Default:</b>	10
<b>Range:</b>	0-15
<b>Unit:</b>	-1dBm
<b>Description:</b>	Controls fax transmission level

FLOW CONTROL	
<b>Type:</b>	Configuration
<b>Format:</b>	AT [cmds] \G <i>n</i> [cmds]
<b>Description:</b>	Selects modem port flow control
Command	Function
\G0	Flow control disabled
\G1	Flow control enabled

FLOW CONTROL CHARACTER - XOFF	
<b>Type:</b>	Register
<b>Format:</b>	AT [cmds] S33= <i>n</i> [cmds]
<b>Default:</b>	19
<b>Range:</b>	0-255
<b>Unit:</b>	ASCII
<b>Description:</b>	Sets the character used to represent XOFF

FLOW CONTROL CHARACTER - XON	
<b>Type:</b>	Register
<b>Format:</b>	AT [cmds] S32= <i>n</i> [cmds]
<b>Default:</b>	17
<b>Range:</b>	0-255
<b>Unit:</b>	ASCII
<b>Description:</b>	Sets the character used to represent XON

Continued on next page . . .

COMPUTER PERIPHERALS, INC.  
VIVA 14.4/FAX INTERNAL

...continued from previous page

LEASED LINE TRANSMISSION LEVEL	
<b>Type:</b>	Register
<b>Format:</b>	AT [cmds] S99= <i>n</i> [cmds]
<b>Default:</b>	10
<b>Range:</b>	0-15
<b>Unit:</b>	-1 dBm
<b>Description:</b>	Sets the signal level for transmission when in leased-line mode

LINE SIGNAL LEVEL	
<b>Type:</b>	Immediate
<b>Format:</b>	AT [cmds] %L [cmds]
<b>Description:</b>	Returns received line signal level

LINE TYPE	
<b>Type:</b>	Configuration
<b>Format:</b>	AT [cmds] %M <i>n</i> [cmds]
<b>Description:</b>	Selects AUXCTL output
Command	Function
%M0	AUXCTL output low enabled
%M1	AUXCTL output high enabled

MAXIMUM BLOCK SIZE FOR TRANSMISSION	
<b>Type:</b>	Configuration
<b>Format:</b>	AT [cmds] \A <i>n</i> [cmds]
<b>Description:</b>	Sets the maximum transmittable block size
Command	Function
\A0	MNP block size is 64 characters
\A1	MNP block size is 128 characters
\A2	MNP block size is 192 characters
f \A3	MNP block size is 256 characters

MNP STREAM/BLOCK MODE	
<b>Type:</b>	Configuration
<b>Format:</b>	AT [cmds] \L <i>n</i> [cmds]
<b>Description:</b>	Selects the transfer mode for MNP
Command	Function
f \L0	Stream mode for MNP enabled
\L1	Block mode for MNP enabled

Continued on next page . . .

COMPUTER PERIPHERALS, INC.  
VIVA 14.4/FAX INTERNAL

...continued from previous page

PSTN TRANSMIT LEVEL	
<b>Type:</b>	Register
<b>Format:</b>	AT [cmds] S91= <i>n</i> [cmds]
<b>Default:</b>	10
<b>Range:</b>	0-15
<b>Unit:</b>	-1dBm
<b>Description:</b>	Controls PSTN transmission level

REPORT LINE SIGNAL QUALITY	
<b>Type:</b>	Immediate
<b>Format:</b>	AT [cmds] %Q [cmds]
<b>Description:</b>	Reports line signal quality. If the value is greater than 7, the modem will retrain.

SLEEP TIMER	
<b>Type:</b>	Register
<b>Format:</b>	AT [cmds] S24= <i>n</i> [cmds]
<b>Default:</b>	0
<b>Range:</b>	0-255
<b>Unit:</b>	1 second
<b>Description:</b>	Maximum duration of DTE and DCE inactivity allowed prior to initiating low-power sleep mode

TEST MODE - PTT	
<b>Type:</b>	Immediate
<b>Format:</b>	AT [cmds] %T [cmds]
<b>Description:</b>	Send PTT test signals for European line test

V.23 SPLIT BAUD MODE	
<b>Type:</b>	Configuration
<b>Format:</b>	AT [cmds] \W <i>n</i> [cmds]
<b>Description:</b>	Controls V.23 split baud mode
<b>Command</b>	<b>Function</b>
\W0	V.23 split baud mode disabled
\W1	V.23 split baud mode enabled

V.23 SPEED DIRECTION	
<b>Type:</b>	Configuration
<b>Format:</b>	AT [cmds] %F <i>n</i> [cmds]
<b>Description:</b>	Selects V.23 speed and direction
<b>Command</b>	<b>Function</b>
%F1	1200bps receive/75bps transmit enabled
%F2	1200bps transmit/75bps receive enabled