


PROMETHEUS HOME OFFICE 144I

| | |
|-------------------------------------|--|
| Card Type | Fax, Modem (asynchronous), Voice |
| Chip Set | Unidentified |
| I/O Options | Speakerphone, Voice-mail |
| Maximum Data Rate | 14.4Kbps |
| Maximum Fax Rate | 14.4Kbps |
| Data Bus | 8-bit ISA |
| Fax Class | Class I & II |
| Data Modulation Protocol | Bell 103/212A |
| | ITU-T V.21, V.22, V.22bis, V.23, V.32, V.32bis |
| Fax Modulation Protocol | ITU-T V.17, V.21CH2, V.27ter, V.29 |
| Error Correction/Compression | MNP5, V.42, V.42bis |



| CONNECTIONS | | | |
|-------------|-------|---------------|-------|
| Function | Label | Function | Label |
| Line in | CN1 | Speaker out | CN3 |
| Line out | CN2 | Microphone in | CN4 |

| USER CONFIGURABLE SETTINGS | | |
|----------------------------|-------|----------|
| Function | Label | Position |
| Speaker plug - normal | JP2 | Closed |
| Speaker plug - monaural | JP2 | Open |

| SERIAL PORT ADDRESS | | |
|---------------------|--------|--------|
| Setting | JP1/A | JP1/B |
| COM1 (3F8h) | Open | Open |
| COM2 (2F8h) | Closed | Open |
| COM3 (3E8h) | Open | Closed |
| COM4 (2E8h) | Closed | Closed |

| INTERRUPT | | | | |
|-----------|--------|--------|--------|--------|
| Setting | JP1/C | JP1/D | JP1/E | JP1/F |
| 2 | Closed | Open | Open | Open |
| 3 | Open | Closed | Open | Open |
| 4 | Open | Open | Closed | Open |
| 5 | Open | Open | Open | Closed |

Continued on next page . . .

Proprietary AT Command Set

| AUTO-RELIABLE FALLBACK CHARACTER | |
|----------------------------------|--|
| Type: | Configuration |
| Format: | AT [cmds] %An [cmds] |
| Default: | Unidentified |
| Range: | 0-127 |
| Unit: | ASCII |
| Description: | Sets the character used as the auto-reliable fallback character; %A0 will disable this function. |

| AUTO-RELIABLE TIME BUFFER CONFIGURATION | |
|---|--|
| Type: | Configuration |
| Format: | AT [cmds] \Cn [cmds] |
| Description: | Controls the handling of incoming data during auto-reliable time period |
| Command | Function |
| í \C0 | Data is discarded |
| \C1 | Data is buffered |
| \C2 | Data is discarded; modem returns to normal mode on receiving auto-reliable fallback character. |

| AUTO-RETRAIN | |
|---------------------|----------------------------|
| Type: | Configuration |
| Format: | AT [cmds] %En [cmds] |
| Description: | Controls auto-retrain mode |
| Command | Function |
| %E0 | Auto-retrain disabled |
| í %E1 | Auto-retrain enabled |

| BREAK TYPE | |
|---------------------|-----------------------------------|
| Type: | Configuration |
| Format: | AT [cmds] \Kn [cmds] |
| Default: | 5 |
| Range: | 0-5 |
| Description: | Configures action of break signal |

| COMPRESSION | |
|---------------------|---------------------------|
| Type: | Configuration |
| Format: | AT [cmds] %Cn [cmds] |
| Description: | Selects data compression |
| Command | Function |
| %C0 | Data compression disabled |
| í %C1 | MNP5 enabled |

PROMETHEUS

HOME OFFICE 144I

. . . continued from previous page

| CONNECT MODE | |
|---------------------|---|
| Type: | Configuration |
| Format: | AT [cmds] \Nn [cmds] |
| Description: | Controls the type of connection the modem will operate in |
| Command | Function |
| \N0 | Normal mode enabled |
| \N1 | Direct mode enabled |
| \N2 | MNP reliable mode enabled |
| \N3 | Auto-reliable mode enabled |
| \N4 | V.42 reliable mode enabled |
| \N5 | V.42 auto-reliable mode enabled |
| í \N6 | Reliable mode enabled |

| DICTIONARY SIZE | |
|---------------------|------------------------|
| Type: | Configuration |
| Format: | AT [cmds] %Dn [cmds] |
| Description: | Select dictionary size |
| Command | Function |
| %D0 | Select 1/2K dictionary |
| %D1 | Select 1K dictionary |
| í %D2 | Select 2K dictionary |

| FLOW CONTROL | |
|---------------------|---------------------------------|
| Type: | Configuration |
| Format: | AT [cmds] \Gn [cmds] |
| Description: | Selects modem port flow control |
| Command | Function |
| í \G0 | Flow control disabled |
| \G1 | Flow control enabled |

| FLOW CONTROL TYPE | |
|---------------------|---|
| Type: | Configuration |
| Format: | AT [cmds] \Qn [cmds] |
| Description: | Sets type of flow control used by modem |
| Command | Function |
| \Q0 | Flow control disabled |
| \Q1 | Bidirectional XON/XOFF flow control enabled |
| \Q2 | CTS flow control by DCE enabled |
| í \Q3 | Bidirectional RTS/CTS flow control enabled |
| \Q4 | Unidirectional XON/XOFF flow control by DCE enabled |

Continued on next page . . .

PROMETHEUS

HOME OFFICE 144I

. . . continued from previous page

| INACTIVITY TIMER | |
|---------------------|---|
| Type: | Configuration |
| Format: | AT [cmds] \Tn [cmds] |
| Default: | 0 |
| Range: | 0-90 |
| Unit: | 1 minute |
| Description: | Sets the length of time that the modem does not receive information before it disconnects. \T=0 will disable timer. |

| MNP RESULT CODES | |
|---------------------|---------------------------|
| Type: | Configuration |
| Format: | AT [cmds] \Vn [cmds] |
| Description: | Selects MNP result codes |
| Command | Function |
| i \V0 | MNP result codes disabled |
| \V1 | MNP result codes enabled |

| REPORT INFORMATION | |
|---------------------|---------------------------------|
| Type: | Immediate |
| Format: | AT [cmds] I n [cmds] |
| Description: | Displays information requested |
| Command | Function |
| I0 | Reports 3 digit product code |
| I1 | Reports ROM checksum |
| I2 | Reports OK |
| I3 | Reports firmware revision level |
| I4 | Reports configuration settings |

| XON/XOFF PASS-THROUGH | |
|-----------------------|---|
| Type: | Configuration |
| Format: | AT [cmds] \Xn [cmds] |
| Description: | Selects whether XON/XOFF signals are sent to remote modem |
| Command | Function |
| i \X0 | XON/XOFF signals trapped by local modem |
| \X1 | XON/XOFF passed through local modem |