
Card Type Chip Set I/O Options

Maximum Modem Rate Maximum Fax Rate Data Bus Fax Class Data Modulation Protocol

Fax Modulation Protocol Error Correction/Compression Fax, Modem (asynchronous), Sound card Unidentified Audio line in, Audio line out, CD-ROM interface, Microphone, MIDI/game port, Speakerphone 14.4Kbps 14.4Kbps 16-bit ISA Class II Bell 103/212A ITU-T V.22, V.22bis, V.32, V.32bis ITU-T V.27ter, V.29 MNP5, V.42, V.42bis



CONNECTIONS			
Function	Label	Function	Label
CD-ROM connector	CN1	Microphone	CN5
Audio line out	CN2	Audio line in	CN6
Phone line out	CN3	MIDI/game port	CN7
Phone line in	CN4		

	DM	A CHANNEL SELECT	ION	
Channel	JB4/I	JB4/J	JB4/K	JB4/L
0	Off	On	On	Off
í 1	On	Off	Off	On
3	On	Off	On	Off
None	Off	Ön	Off	On

... continued from previous page

	I/O	ADDRESS SELECTI	ON	
Setting	JB4/A	JB4/B	JB4/C	JB4/D
220	Off	On	Off	On
230	Off	On	On	Off
í 240	On	Off	Off	On
250	On	Off	On	Off

	IN	TERRUPT SELECTIC	DN .	
IRQ	JB4/E	JB4/F	JB4/G	JB4/H
í IRQ5	Off	On	On	Off
IRQ7	On	Off	Off	On
IRQ9	Off	On	Off	On
IRQ10	On	Off	On	Off

	JOYSTICK CONTROL	
Setting	JB4/M	JB4/N
í Enabled	On	Off
Disabled	Off	On

	MODEM CONTROL	
Setting	JB1/Pins 1 & 2	JB1/Pins 3 & 4
í Enabled	Closed	Open
Disabled	Open	Closed

	SERIAL PORT ADDRESS SELECTION			
Setting	JB2/G	JB2/H	JB2/I	JB2/J
COM1 (3F8h)	Off	On	Off	On
COM2 (2F8h)	Off	On	On	Off
í COM3 (3E8h)	On	Off	Off	On
COM4 (2E8h)	On	Off	On	Off

	SERIAL PORT 1 INTERRUPT SELECTION					
IRQ	JB2/A	JB2/B	JB2/C	JB2/D	JB2/E	JB2/F
IRQ3	On	Off	Off	Off	Off	Off
IRQ4	Off	On	Off	Off	Off	Off
IRQ5	Off	Off	On	Off	Off	Off
IRQ7	Off	Off	Off	On	Off	Off
í IRQ10	Off	Off	Off	Off	On	Off
IRQ11	Off	Off	Off	Off	Off	On

SOUND CARD CONTROL		
Setting	JB3/Pins 1 & 2	JB3/Pins 3 & 4
í Enabled	Closed	Open
Disabled	Open	Closed

... continued from previous page

# **Proprietary AT Command Set**

	AUTO-RELIABLE TIME BUFFER CONFIGURATION
Туре:	Configuration
Format:	AT [cmds] \C <i>n</i> [cmds]
Description:	Controls the handling of incoming data during auto-reliable time period
Command	Function
\C0	Data is discarded
\C1	Data is buffered
\C2	Data is discarded; modem returns to normal mode on receiving auto-reliable
	fallback character.

	AUTO-RETRAIN - AUTO-FALLBACK/FALL-FORWARD
Туре:	Configuration
Format:	AT [cmds] %E <i>n</i> [cmds]
Description:	Controls auto-retrain mode and fallback/fall-forward
Command	Function
%E0	Auto-retrain disabled
%E1	Auto-retrain enabled

	BREAK TYPE
Туре:	Configuration
Format:	AT [cmds] \K <i>n</i> [cmds]
Description:	Configures action of break signal
Command	Function
\K0	Online command mode enabled, send no break to remote modem
\K1	Break sent to remote modem and buffered cleared
\K2	Online command mode enabled, send no break to remote modem
\K3	Send break to remote modem immediately
\K4	Online command mode enabled, send no break to remote modem
\K5	Send break with transmitted data

BUFFER SIZE - LOWER LIMIT	
Туре:	Register
Format:	AT [cmds] S49= <i>n</i> [cmds]
Default:	10
Range:	0-255
Unit:	1 byte
Description:	Controls the low-end size of the buffer during error-control mode

... continued from previous page

	BUFFER SIZE - UPPER LIMIT
Type:	Register
Format:	AT [cmds] S50= <i>n</i> [cmds]
Default:	200
Range:	2-255
Unit:	1 byte
Description:	Controls the high-end size of the buffer during error-control mode

COMPRESSION	
Туре:	Configuration
Format:	AT [cmds] %C <i>n</i> [cmds]
Description:	Selects data compression
Command	Function
%C0	Data compression disabled
%C1	MNP5 enabled

CONNECT MODE	
Type:	Configuration
Format:	AT [cmds] \N <i>n</i> [cmds]
Description:	Controls the type of connection the modem will operate in
Command	Function
\N0	Normal mode enabled
\N1	Direct mode enabled
\N2	MNP reliable mode enabled
\N3	Auto-reliable mode enabled
\N4	V.42 reliable mode enabled
\N5	V.42 auto-reliable mode enabled
\N6	Reliable mode enabled

	DIAL
Туре:	Immediate
Format:	AT [cmds] D<#> [cmds]
Description:	Dials telephone number according to any modifiers included in the string
Note:	Any combination of modifiers can be used to produce the desired dial functions in
	sequence.
Modifier	Function
L	Re-dial last number
Р	Pulse dialing enabled
Sn	Dial stored telephone number <i>n</i>
Т	Tone dialing enabled
W	Dialing resumed following dial tone detection for amount of time specified in S7
	register
,	Dialing paused for amount of time specified in S8 register
!	Modem commanded to go off-hook for .5 second before returning on-hook
@	Wait for quiet answer for amount of time specified in S7 register
;	Modem returned to command state after dialing

... continued from previous page

	DICTIONARY SIZE
Туре:	Configuration
Format:	AT [cmds] %D <i>n</i> [cmds]
Description:	Select dictionary size
Command	Function
Command %D0	Function Select 1/2K bytes

EXTENDED RESULT CODES	
Туре:	Configuration
Format:	AT [cmds] \V <i>n</i> [cmds]
Description:	Selects extended result codes
Command	Function
\V0	Extended result codes disabled
\V1	Extended result codes enabled

	FLOW CONTROL
Туре:	Configuration
Format:	AT [cmds] \G <i>n</i> [cmds]
Description:	Selects modem port flow control
Command	Function
\G0	Flow control disabled
\G1	Flow control enabled

	FLOW CONTROL TYPE
Туре:	Configuration
Format:	AT [cmds] \Q <i>n</i> [cmds]
Description:	Sets type of flow control used by modem
Command	Function
\Q0	Flow control disabled
\Q1	XON/XOFF, bi-directional RTS/CTS flow control enabled
\Q2	Unidirectional CTS flow control enabled
\Q3	Bi-directional RTS/CTS flow control enabled
\Q4	Unidirectional XON/XOFF flow control by DCE enabled

	INACTIVITY TIMER
Туре:	Configuration
Format:	AT [cmds] \T <i>n</i> [cmds]
Default:	0
Range:	0-90
Unit:	1 minute
Description:	Sets the length of time that the modem does not receive information before it disconnects.
Note:	AT\T0 will disable timer.
NOLE.	

... continued from previous page

	REPORT INFORMATION	
Type:	Immediate	
Format:	AT [cmds] I <i>n</i> [cmds]	
Description:	Displays information requested	
Command	Function	
10	Reports product code	
1	Reports ROM checksum	
12	Tests and reports ROM checksum	
13	Reports firmware revision	
14	Reports current configuration	

	XON/XOFF PASS-THROUGH
Туре:	Configuration
Format:	AT [cmds] \X <i>n</i> [cmds]
Description:	Selects whether XON/XOFF signals are sent to remote modem
Command	Function
\X0	XON/XOFF signals trapped by local modem
\X1	XON/XOFF passed through local modem