
CARDINAL TECHNOLOGIES, INC

14400BPS V.32BIS DIGITAL

| Card Type |
|--------------------------|
| Chip Set |
| I/O Options |
| Maximum Modem Rate |
| Maximum Fax Rate |
| Data Modulation Protocol |

Fax Modulation Protocol Error Correction/Compression Fax Class Data Bus Modem Unidentified Line in, line out 14.4Kbps 14.4Kbps Bell 103/212A

ITU-T V.21, V.22, V.22bis, V.32, V.32bis ITU-T V.17, V.21 CH 2, V.27ter, V.29 MNP5, V.42, V.42bis Class I & II 8-bit ISA



| | CONNECTIONS | | |
|------------------|---------------------|-----------------|-------|
| Function | Label | Function | Label |
| Line out (RJ-11) | CN1 | Line in (RJ-11) | CN2 |
| | SERIAL PORT ADDRESS | | |
| Setting | JP1/A | JP1/B | |
| COM1 (3F8h) | Closed | Closed | |
| » COM2 (2F8h) | Open | Closed | |
| COM3 (3E8h) | Closed | Open | |
| COM4 (2E8h) | Open | Open | |
| | | | |

| | INTERRUI | PŢ | | |
|---------|----------|-------|-------|-------|
| Setting | JP1/C | JP1/D | JP1/E | JP1/F |

| IRQ2 | Open | Open | Open | Closed |
|--------|--------|--------|--------|--------|
| » IRQ3 | Open | Closed | Open | Open |
| IRQ4 | Closed | Open | Open | Open |
| IRQ5 | Open | Open | Closed | Open |

SUPPORTED COMMAND SET

Basic AT Commands

AT, **■+++■**, A/

A, B, E, H, O, Q, M, V

&C, &F, &V

Extended AT Commands

١N

S Registers

S0, S1, S2, S3, S4, S5, S6, S7, S8, S9, S10, S11, S18, S14, S16, S18

Special Commands

Note: Please see MHI Help file for full command documentation.

Proprietary AT Command Set

| DATA SET READY (DSR) | | |
|----------------------|---|--|
| Туре: | Configuration | |
| Format: | AT [cmds] &Sn [cmds] | |
| Description: | Selects DSR options | |
| Command | Function | |
| ■ &S0 | DSR forced high | |
| &S1 | DSR high only while modem is handshaking or connected | |

| Туре: | Configuration |
|--------------|---------------------------------------|
| Format: | AT [cmds] &D <i>n</i> [cmds] |
| Description: | Selects modem response to DTR |
| Command | Function |
| &D0 | DTR ignored |
| &D1 | DTR toggle causes online command mode |
| ■ &D2 | DTR toggle causes modem to go on-hook |
| &D3 | Modem reset on DTR toggle |

| | DIAL |
|--------------|---|
| Туре: | Immediate |
| Format: | AT [cmds] D<#> [cmds] |
| Description: | Dials telephone number according to any modifiers included in the string |
| Note: | Any combination of modifiers can be used to produce the desired dial functions in sequence. |
| Modifier | Function |
| DP | Pulse dialing enabled |
| DR | Answer mode enabled, originate mode disabled following handshake initiation |
| DT | Tone dialing enabled |
| DW | Dialing resumed following dial tone detection |
| D, | Dialing paused for amount of time specified in S8 register |
| D! | Modem commanded to go off-hook for .5 seconds before returning on-hook |
| D@ | Wait for quiet answer |
| D; | Modem returned to command state after dialing |

EXTENDED RESULT CODES



Configuration

Format:

Enables selection of additional result codes

| Command | Function |
|---------|---|
| W0 | Enables CONNECT result codes to report DTE to DCE speed |
| W1 | Enables CONNECT result codes to report error correction |

| | FLOW CONTROL |
|--------------|---|
| Туре: | Configuration |
| Format: | AT [cmds] &Kn [cmds] |
| Description: | Enables flow control options |
| Command | Function |
| &K0 | Flow control disabled |
| ■ &K3 | RTS/CTS flow control enabled |
| &K4 | XON/XOFF flow control enabled |
| &K5 | Transparent XON/XOFF flow control enabled |

| | PULSE DIALING RATIO |
|--------------|-------------------------------------|
| Туре: | Configuration |
| Format: | AT [cmds] &Pn [cmds] |
| Description: | Selects pulse dial make/break ratio |
| Command | Function |
| ■ &P0 | 39/61ms at 10pps (North America) |
| &P1 | 33/67ms at 10pps (Europe) |
| &P2 | 39/61ms at 20pps |
| | REPORT INFORMATION |

| Туре: | Immediate |
|--------------|--------------------------------|
| Format: | AT [cmds] In [cmds] |
| Description: | Displays information requested |

Function

| 10 | Reports product code |
|----|--------------------------------|
| 11 | Reports ROM checksum |
| 12 | Tests and reports ROM checksum |
| 13 | Reports modem capabilities |

SELECT CALL PROGRESS RESULT CODES

| Туре: | Configuration | |
|--------------|---|--|
| Format: | AT [cmds] Xn [cmds] | |
| Description: | Enables selection of tone detection and associated result code format options | |
| Command | Function | |
| X0 | Busy and dial tone detection disabled; result codes 0 - 4, 8 enabled. | |
| X1 | Busy and dial tone detection disabled; result codes 0 - 5, 8 & 10 - 15 enabled. | |
| X2 | Busy tone detection disabled, dial tone detection enabled; result codes 0 - 6, 8 & 10 - 15 enabled. | |
| Х3 | Busy tone detection enabled, dial tone detection disabled; result codes 0 - 8, & 10 - 15 enabled. | |
| ■ X4 | Busy and dial tone detection enabled; result codes 0 - 7 & 10 enabled. | |
| X5 | Busy and dial tone detection enabled; result codes 0 - 4, 6 - 8 enabled. | |

| | SOFT RESET |
|--------------|--|
| Туре: | Immediate |
| Format: | AT [cmds] Zn [cmds] |
| Description: | Restores modem profiles previously saved in non-volatile RAM using the &W command. |
| Command | Function |
| Z0 | Restore setting |

EXTENDED AT COMMAND SET

| | | COMPRESSION | |
|-------|---------------|-------------|--|
| Туре: | Configuration | | |

 Format:
 AT [cmds] %Cn [cmds]

 Description:
 Selects data compression

 Command
 Function

 %C0
 Data compression disabled

 %C1
 MNP5 enabled

S(status) REGISTERS

| DCE LINE SPEED | | |
|----------------|---|--|
| Туре: | Register | |
| Format | AT [cmds] S37= <i>n</i> [cmds] | |
| Description: | Sets the maximum allowable data exchange rate attempted during handshake process. | |
| Command | Function | |
| S37=0 | Current DTE rate | |
| S37=1 | V.21 at 300bps | |
| S37=2 | Bell 103 at 300bps | |
| S37=5 | V.22 at 1200bps | |
| S37=6 | V.22bis at 2400bps | |
| S37=8 | V.32 at 4800bps | |
| S37=9 | V.32 at 9600bps | |
| S37=10 | V.32bis at 12.0Kbps | |
| S37=11 | V.32bis at 14.4Kbps | |
| S27=12 | V.32bis at 7200bps | |