


ACER OPEN
ACERMAGIC S20 (M1 ENHANCED)

Card Type	Sound card
Chipset Controller	Unidentified
I/O Options	Audio in, CD-ROM audio, CD-ROM interface (4), game/MIDI port, microphone in, speaker/line out, volume, wavetable
Maximum DRAM	N/A



CONNECTIONS			
Purpose :	Location	Purpose :	Location
Mitsumi CD-ROM interface	CN1	Wavetable module connector	CN7
Sony CD-ROM interface	CN2	Speaker/line out	J1
Panasonic CD-ROM interface	CN3	Audio line in	J2
IDE CD-ROM interface	CN4	Mic in	J3
Game/MIDI port	CN5	Volume	VR1
CD-ROM audio in	CN6		

AUDIO OUTPUT AMPLIFIER CONFIGURATION		
Setting	J5	J6
Speaker	Pins 1 & 3 closed	Pins 1 & 3 closed
Line out	Pins 2 & 4 closed	Pins 2 & 4 closed