MEDIA VISION TECHNOLOGY, INC.
GETTING STARTED (SANYO 94A/123)

Card Type   Sound card
Chipset Controller Media Vision
I/O Options   CD-ROM audio in (3), CD-ROM interface (3), game/MIDI port, line in, line
                       out, microphone, wavetable connector
Maximum DRAM   N/A

CONNECTIONS			
Purpose	Location	Purpose	Location
Line in	J1	Mitsumi CD-ROM interface	J10
Mic in	J2	Panasonic CD-ROM interface	J11
Line out	J3	Sony CD - audio in	J14
Wavetable connector	J4	Panasonic CD - audio in	J15
Game/MIDI port	J5	Mitsumi CD - audio in	J16
Sony CD-ROM interface	J9		

DMA SHARING CONFIGURATION	
Setting	J8
No DMA sharing	Pins 2 & 3 closed
DMA sharing	Pins 1 & 2 closed

MPU 401 CONFIGURATION	
Setting	J18
í Enabled	Open
Disabled	Closed

GAME PORT CONFIGURATION	
Setting	J19
í Enabled	Open
Disabled	Closed