Chapter 5: Jumper Settings
STANDARD MICROSYSTEMS CORPORATION
I N T E R N A L   T W I S T E D   P A I R   H U B

NIC Type	Arcnet
Transfer Rate	2.5Mbps
Data Bus	8-bit ISA
Topology	Star
Wiring Type	Unshielded twisted pair
Boot ROM	Not available

CONNECTIONS			
Purpose	Location	Purpose	Location
RJ11 ports 1-4	J1 - J4	Internal hub connectors	JP1 & JP2

1

THE NETWORK INTERFACE CARD TECHNICAL GUIDE
STANDARD MICROSYSTEMS CORPORATION
I N T E R N A L   T W I S T E D   P A I R   H U B

DIAGNOSTIC LED(S)			
LED	Color	Status	Condition
LED1	Green	On	Data is being transmitted/received on J2
LED1	Green	Off	Data is not being transmitted/received on J2
LED1	Green	Blinking	Reconfiguration or J2
LED2	Green	On	Data is being transmitted/received on J3
LED2	Green	Off	Data is not being transmitted/received on J3
LED2	Green	Blinking	Reconfiguration on J2
LED3	Green	On	Data is being transmitted/received on J4
LED3	Green	Off	Data is not being transmitted/received on J4
LED3	Green	Blinking	Reconfiguration on J2
LED4	Green	On	Data is being transmitted/received on J1
LED4	Green	Off	Data is not being transmitted/received on J1
LED4	Green	Blinking	Reconfiguration on J2
LED5	Red	On	Polarity is reversed
LED5	Red	Off	Polarity is not reversed