


CNET TECHNOLOGY, INC.  
CN 160A

NIC Type	ARCnet
Transfer Rate	2.5Mbps
Data Bus	16-bit ISA
Topology	Star
Wiring Type	RG-62/U 93ohm coaxial
Boot ROM	Available



NODE ADDRESS								
Node	SW2/1	SW2/2	SW2/3	SW2/4	SW2/5	SW2/6	SW2/7	SW2/8
0	-	-	-	-	-	-	-	-
1	Off	On	On	On	On	On	On	On
2	On	Off	On	On	On	On	On	On
3	Off	Off	On	On	On	On	On	On
4	On	On	Off	On	On	On	On	On
251	Off	Off	On	Off	Off	Off	Off	Off
252	On	On	Off	Off	Off	Off	Off	Off
253	Off	On	Off	Off	Off	Off	Off	Off
254	On	Off	Off	Off	Off	Off	Off	Off
255	Off	Off	Off	Off	Off	Off	Off	Off

Note: Node address 0 is used for messaging between nodes and must not be used.  
A total of 255 node address settings are available. The switches are a binary representation of the decimal node addresses. Switch 1 is the Least Significant Bit and switch 8 is the Most Significant Bit. The switches have the following decimal values: switch 1=1, 2=2, 3=4, 4=8, 5=16, 6=32, 7=64, 8=128. Turn off the switches and add the values of the off switches to obtain the correct node address. (On=0, off=1)

Continued on next page . . .

# CNET TECHNOLOGY, INC.

## C N 1 6 0 A

... continued from previous page

RESPONSE/RECONFIGURATION TIMEOUTS			
Response Time	Reconfiguration Time	JP1	JP2
74.7 $\mu$ s	840ms	Open	Open
283.4 $\mu$ s	1680ms	Closed	Open
561.8 $\mu$ s	1680ms	Open	Closed
1118.6 $\mu$ s	1680ms	Closed	Closed
Note: All NICs on the network must have this option set the same.			

INTERRUPT REQUEST											
IRQ	JP3	JP4	JP5	JP6	JP7	JP8	JP9	JP10	JP11	JP12	JP13
i2	Open	Open	Open	Open	Open	Open	Open	Open	Open	Open	Closed
3	Open	Open	Open	Open	Open	Closed	Open	Open	Open	Open	Open
4	Open	Open	Open	Open	Open	Open	Closed	Open	Open	Open	Open
5	Open	Open	Open	Open	Open	Open	Open	Closed	Open	Open	Open
7	Open	Open	Open	Open	Open	Open	Open	Open	Open	Closed	Open
10	Open	Open	Open	Open	Closed	Open	Open	Open	Open	Open	Open
11	Open	Open	Open	Closed	Open	Open	Open	Open	Open	Open	Open
12	Open	Open	Closed	Open	Open	Open	Open	Open	Open	Open	Open
15	Open	Closed	Open	Open	Open	Open	Open	Open	Open	Open	Open

I/O BASE ADDRESS						
Address	SW1/1	SW1/2	SW1/3	SW1/4	SW1/5	SW1/6
260h	Off	On	On	Off	Off	On
290h	Off	On	Off	On	On	Off
i2E0h	Off	On	Off	Off	Off	On
2F0h	Off	On	Off	Off	Off	Off
300h	Off	Off	On	On	On	On
350h	Off	Off	On	Off	On	Off
380h	Off	Off	Off	On	On	On
3E0h	Off	Off	Off	Off	Off	On

BASE MEMORY ADDRESS & BOOT ROM ADDRESS (REV.D, VER: A 05-01-0005-( 3 )					
Base Address	Boot ROM Address	SW1/7	SW1/7	SW1/9	SW1/10
C0000h	C8000h	Off	Off	On	On
iD0000h	D8000h	Off	Off	On	Off
E0000h	E8000h	Off	Off	Off	On

Continued on next page ...

... continued from previous page

BASE MEMORY ADDRESS & BOOT ROM ADDRESS (VER: A 05-01-0005-04 OR ABOVE)					
Base Address	Boot ROM Address	SW1/7	SW1/8	SW1/9	SW1/10
C0000h	C2000h	On	On	On	On
C4000h	C6000h	On	On	On	Off
CC000h	CE000h	On	On	Off	Off
FD0000h	D2000h	On	Off	On	On
D4000h	D6000h	On	Off	On	Off
D8000h	DA000h	On	Off	Off	On
DC000h	DE000h	On	Off	Off	Off
E0000h	E2000h	Off	On	On	On

DIAGNOSTIC LED(S)		
LED	Status	Condition
LED1	On	Link integrity is good
LED1	Off	Link integrity is broken
LED2	On	Data is being transmitted or recieved
LED2	Off	Data is not being transmitted or recieved