
## EDIMAX COMPUTER COMPANY EN-3360 (Version 2.2)

NIC Type Ethernet
Transfer Rate 10Mbps
Data Bus 16-bit ISA
Topology Linear Bus

Wiring Type RG-58A/U 50ohm coaxial
AUI transceiver via DB-15 port

Boot ROM Available



	CABLE TYPE	
Type	JP2	JP3A-JP3F
íRG-58A/U 50ohm coaxial	Pins 1 & 2 closed	Pins 2 & 3 closed
AUI transceiver via DB-15 port	Pins 2 & 3 closed	Pins 1 & 2 closed

COMPATIBILITY MODE		
JP4		
Pins 2 & 3 closed		
Pins 1 & 2 closed		

Note: On some systems the data bus timing is not truly IBM PC/AT compatible. If the card is not initializing, enabling compatibility mode may allow the card to operate properly.

		BOOT ROM ADDRESS	6	
Address	JP5A	JP5B	JP5C	JP5D
C0000h	Closed	Closed	Closed	Closed
C4000h	Open	Closed	Closed	Closed
íC8000h	Closed	Open	Closed	Closed
CC000h	Open	Open	Closed	Closed
D0000h	Closed	Closed	Open	Closed
D4000h	Open	Closed	Open	Closed
D8000h	Closed	Open	Open	Closed
DC000h	Open	Open	Open	Closed

Continued on next page . . .

## EDIMAX COMPUTER COMPANY EN-3360 (Version 2.2)

. . . continued from previous page

BOOT ROM		
Setting	JP6	
íDisabled	Open	
Enabled	Closed	

I/O BASE ADDRESS				
Address	JP7A	JP7B		
í300h	Closed	Closed		
320h	Open	Closed		
340h	Closed	Open		
360h	Open	Open		

		INTERRUPT SETTINGS	3	
IRQ	JP7C	JP7D	JP7E	JP7F
2/9	Closed	Open	Open	Open
í3	Open	Closed	Open	Open
4	Open	Open	Closed	Open
5	Open	Open	Open	Closed