


MULTI-TECH SYSTEMS, INC.
AN301CX8/AN301CXB8

NIC Type	ARCnet
Transfer Rate	2.5Mbps
Data Bus	8-bit ISA
Topology	Star (AN301CX8) Linear bus (AN301CXB8)
Wiring Type	RG-62A/U 93ohm coaxial
Boot ROM	Available



NODE ADDRESS								
Node	SW2/1	SW2/2	SW2/3	SW2/4	SW2/5	SW2/6	SW2/7	SW2/8
0	-	-	-	-	-	-	-	-
1	Off	On	On	On	On	On	On	On
2	On	Off	On	On	On	On	On	On
3	Off	Off	On	On	On	On	On	On
4	On	On	Off	On	On	On	On	On
251	Off	Off	On	Off	Off	Off	Off	Off
252	On	On	Off	Off	Off	Off	Off	Off
253	Off	On	Off	Off	Off	Off	Off	Off
254	On	Off	Off	Off	Off	Off	Off	Off
255	Off	Off	Off	Off	Off	Off	Off	Off

Note: Node address 0 is used for messaging between nodes and must not be used.
A total of 255 node address settings are available. The switches are a binary representation of the decimal node addresses. Switch 1 is the Least Significant Bit and switch 8 is the Most Significant Bit. The switches have the following decimal values: switch 1=1, 2=2, 3=4, 4=8, 5=16, 6=32, 7=64, 8=128. Turn off the switches and add the values of the off switches to obtain the correct node address. (On=0, Off=1)

Continued on next page . . .

MULTI-TECH SYSTEMS, INC.
AN301CX8/AN301CXB8

... continued from previous page

RECONFIGURATION TIMEOUT			
Response Time	Reconfig Time	ET1	ET2
178µs	840ms	Open	Open
285µs	1680ms	Open	Closed
563µs	1680ms	Closed	Open
1130µs	1680ms	Closed	Closed
Note: All NICs on the network segment must have this option set the same.			

BOOT ROM	
Setting	J2
Disabled	Open
Enabled	Closed

INTERRUPT REQUEST						
IRQ	JP3A	JP3B	JP3C	JP3D	JP3E	JP3F
i2/9	Open	Open	Open	Open	Open	Closed
3	Open	Open	Open	Open	Closed	Open
4	Open	Open	Open	Closed	Open	Open
5	Open	Open	Closed	Open	Open	Open
6	Open	Closed	Open	Open	Open	Open
7	Closed	Open	Open	Open	Open	Open

BASE MEMORY ADDRESS & BOOT ROM ADDRESS						
Base	Boot ROM	SW1/1	SW1/2	SW1/3	SW1/4	SW1/5
C0000h	C2000h	Off	Off	Off	Off	Off
C4000h	C6000h	On	Off	Off	Off	Off
CC000h	CE000h	Off	On	Off	Off	Off
iD0000h	D2000h	On	On	Off	Off	Off
D4000h	D6000h	Off	Off	On	Off	Off
D8000h	DA000h	On	Off	On	Off	Off
DC000h	DE000h	Off	On	On	Off	Off
E0000h	E2000h	On	On	On	Off	Off

I/O BASE ADDRESS			
Address	SW1/6	SW1/7	SW1/8
260 - 26Fh	On	On	On
290 - 29Fh	On	On	Off
2E0 - 2EFh	On	Off	On
2F0 - 2FFh	On	Off	Off
300 - 30Fh	Off	On	On
350 - 35Fh	Off	On	Off
380 - 38Fh	Off	Off	On
3E0 - 3EFh	Off	Off	Off

Continued on next page ...

MULTI-TECH SYSTEMS, INC.

AN301CX8/AN301CXB8

... continued from previous page

DIAGNOSTIC LED(S)			
LED	Color	Status	Condition
LED1	Green	On	Data is being transmitted
LED1	Green	Off	Data is not being transmitted
LED2	Red	On	Card is active on host data bus
LED2	Red	Off	No card activity