
THE NETWORK INTERFACE CARD TECHNICAL GUIDE

EDIMAX COMPUTER COMPANY 1000C V2.4

NIC Type Transfer Rate Data Bus Topology Wiring Type

Boot ROM

Ethernet 10Mbps 8-bit ISA Linear Bus RG-58A/U 50ohm coaxial AUI transceiver via DB-15 port Available



CONNECTORS			
Setting	Location		
External power LED.	JP2		
External power LED.	JP2		

I/O BASE ADDRESS			
Address	JP1A	JP1B	JP1C
í300h	Closed	Closed	Closed
320h	Closed	Closed	Open
340h	Closed	Open	Closed
360h	Closed	Open	Open

INTERRUPT SETTINGS						
IRQ	JP1D	JP1E	JP1F	JP1G	JP1H	JP1I
2	Closed	Open	Open	Open	Open	Open
3	Open	Closed	Open	Open	Open	Open
4	Open	Open	Closed	Open	Open	Open
5	Open	Open	Open	Closed	Open	Open
6	Open	Open	Open	Open	Closed	Open
7	Open	Open	Open	Open	Open	Closed

Continued on next page . . .

EDIMAX COMPUTER COMPANY 1000C V2.4

. . . continued from previous page

		DMA CHANNEL		
Channel	JP1J	JP1K	JP1L	JP1M
íDisabled	Closed	Open	Closed	Open
DMA1	Closed	Open	Closed	Open
DMA3	Open	Closed	Open	Closed

		BOOT ROM ADDRES	S	
Address	JP3A	JP3B	JP3C	JP3D
C0000h	Closed	Closed	Closed	Closed
C4000h	Open	Closed	Closed	Closed
íC8000h	Closed	Open	Closed	Closed
CC000h	Open	Open	Closed	Closed
D0000h	Closed	Closed	Open	Closed
D4000h	Open	Closed	Open	Closed
D8000h	Closed	Open	Open	Closed
DC000h	Open	Open	Open	Closed

	CABLE TYPE	
Туре	JP4	JP11
íRG-58A/U 50ohm coaxial	Pins 2 & 3 closed	Pins 2 & 3 closed
AUI transceiver via DB-15 port	Pins 1 & 2 closed	Pins 1 & 2 closed

BOOT ROM		
Setting	JP5	
íDisabled	Open	
Enabled	Closed	