
EDIMAX COMPUTER COMPANY 2000C/EN-3360 V2.4

NIC Type Ethernet
Transfer Rate 10Mbps
Data Bus 16-bit ISA
Topology Linear Bus

Wiring Type RG-58A/U 50ohm coaxial AUI transceiver via DB-15 port

Boot ROM Available



COMPATIBII	LITY MODE			
Setting	JP1			
íDisabled	Pins 1 & 2 closed			
Enabled	PIns 2 & 3 closed			
Note On some systems the data bus timing is no	t truly IBM PC/AT compatible. If the card is not			

Note: On some systems the data bus timing is not truly IBM PC/AT compatible. If the card is not initializing, enabling compatibility mode may allow the card to operate properly.

				11	NTERRUF	T SETTIN	IGS				
IRQ	JP2A	JP2B	JP2C	JP2D	JP2E	JP2F	JP2G	JP2H	JP2I	JP2J	JP2K
2/9	Open	Open	Open	Open	Open	Close d	Open	Open	Open	Open	Open
3	Open	Open	Open	Open	Open	Open	Open	Open	Open	Open	Close d
4	Open	Open	Open	Open	Open	Open	Open	Open	Open	Close d	Open
5	Open	Open	Open	Open	Open	Open	Open	Open	Close d	Open	Open
6	Open	Open	Open	Open	Open	Open	Open	Close d	Open	Open	Open
7	Open	Open	Open	Open	Open	Open	Close d	Open	Open	Open	Open
10	Open	Open	Open	Open	Close d	Open	Open	Open	Open	Open	Open
11	Open	Open	Open	Close d	Open						
12	Open	Open	Close d	Open							

Chapter 5: Jumper Settings

14	Open	Close d	Open								
15	Close d	Open	Open	Open	Open	Open	Open	Open	Open	Open	Open

Continued on next page . . .

EDIMAX COMPUTER COMPANY 2000C V2.4 & EN-3360 V2.4

. . . continued from previous page

	I/O BASE ADDRESS	
Address	JP2L	JP2M
í300h	Closed	Closed
320h	Closed	Open
340h	Open	Closed
360h	Open	Open

ВО	OT ROM
Setting	JP3
íDisabled	Open
Enabled	Closed

		BOOT ROM ADDRESS	3	
Address	JP4A	JP4B	JP4C	JP4D
C0000h	Closed	Closed	Closed	Closed
C4000h	Closed	Closed	Closed	Open
íC8000h	Closed	Closed	Open	Closed
CC000h	Closed	Closed	Open	Open
D0000h	Closed	Open	Closed	Closed
D4000h	Closed	Open	Closed	Open
D8000h	Closed	Open	Open	Closed
DC000h	Closed	Open	Open	Open

	CABLE TYPE	
Type	JP10	JP12
íRG-58A/U 50ohm coaxial	Pins 2 & 3 Closed	Pins 2 & 3 Closed
AUI transceiver via DB-15 port	Pins 1 & 2 Closed	Pins 1 & 2 Closed

FACTORY CONFIGURED SETTINGS				
Jumper Setting				
JP6	Unused			

CONNECTORS				
Setting	Location			
External power LED.	JP11			