
XINETRON, INC. XI221S/XI221B

NIC Type ARCnet
Transfer Rate 2.5Mbps
Data Bus 16-bit ISA
Topology Star
Linear bus

Wiring Type RG-62A/U 93ohm coaxial

Boot ROM Available



	NODE ADDRESS							
Node	SW2/1	SW2/2	SW2/3	SW2/4	SW2/5	SW2/6	SW2/7	SW2/8
0	-	-	-	-	-	-	-	-
1	On	On	On	On	On	On	On	Off
2	On	On	On	On	On	On	Off	On
3	On	On	On	On	On	On	Off	Off
4	On	On	On	On	On	Off	On	On
251	Off	Off	Off	Off	Off	On	Off	Off
252	Off	Off	Off	Off	Off	Off	On	On
253	Off	Off	Off	Off	Off	Off	On	Off
254	Off	Off	Off	Off	Off	Off	Off	On
255	Off	Off	Off	Off	Off	Off	Off	Off

Note: Node address 0 is used for messaging between nodes and must not be used.

A total of 255 node address settings are available. The switches are a binary representation of the decimal node addresses. Switch 8 is the Least Significant Bit and switch 1 is the Most Significant Bit. The switches have the following decimal values: switch 1=128, 2=64, 3=32, 4=16, 5=8, 1=4, 7=2, 8=1. Turn off the switches and add the values of the off switches to obtain the correct node ad Iress. (On=0, Off=1)

Continued on next page . . .

XINETRON, INC. XI221S/XI221B

. . . continued from previous page

RESPONSE AND RECONFIGURATION TIMEOUTS						
Response Time	Ide Time	Reconfiguration Time	JP1	JP2		
í78μs	í86μs	840ms	Open	Open		
285μs	316µs	1680ms	Open	Closed		
563μs	624μs	1680ms	Closed	Open		
1130μs 1237μs 1680ms Closed Closed						
Note: All NICs on the network segment must have this option set the same.						

INTERRUPT REQUEST						
IRQ	JP5A	JP5A	JP5A	JP5A	JP5A	
í2	Closed	Open	Open	Open	Open	
3	Open	Closed	Open	Open	Open	
4	Open	Open	Closed	Open	Open	
5	Open	Open	Open	Closed	Open	
7	Open	Open	Open	Open	Closed	

I/O BASE ADDRESS						
Address	SW1/1	SW1/2	SW1/3	SW1/4	SW1/5	SW1/6
260-26Fh	Off	On	On	Off	Off	On
290-29Fh	Off	On	Off	On	On	Off
í2E0-2EFh	Off	On	Off	Off	Off	On
2F0-2FFh	Off	On	Off	Off	Off	Off
300-30Fh	Off	Off	On	On	On	On
350-35Fh	Off	Off	On	Off	On	Off
380-38Fh	Off	Off	Off	On	On	On
3E0-3EFh	Off	Off	Off	Off	Off	On

BASE MEMORY ADDRESS AND BOOT ROM ADDRESS						
Base Address	Boot ROM Address	SW1/7	SW1/8	SW1/9	SW1/10	
C0000-C07FFh	C2000-C3FFFh	Off	Off	On	On	
íD0000-D07FFh	D2000-D3FFFh	Off	Off	On	Off	
E0000-E07FFh	E2000-E3FFFh	Off	Off	Off	On	

DIAGNOSTIC LED						
LED	Color	Status	Condition			
LED1	Yellow	Blinking	Card is not connected to network			
LED1	Yellow	On	Normal operation			
LED1	Yellow	Flashing	Data is being transmitted/received			
Note: Location of L	Note: Location of LED1 is unknown.					