## Chapter 5: Jumper Settings GVC TECHNOLOGIES, INC. 8 - B | T T H R E E - I N - O N E


NIC Type Ethernet
Transfer Rate 10Mbps
Data Bus 8-bit ISA
Topology Linear Bus/Star

Wiring Type Unshielded Twisted Pair

AUI Transceiver via DB-15 port RG58A/U 50ohm coaxial

RG-58C/A

Boot ROM Available



BOOT ROM CONFIGURATION		
Setting	JP1/A	
Enabled	Closed	
í Disabled	Open	

ADDRESS SELECTION				
Base I/O Address	Boot ROM Address	JP1/B	JP1/C	
300h	C800h	Closed	Closed	
320h	CC00h	Open	Closed	
340h	D000h	Closed	Open	
360h	D400h	Open	Open	

INTERRUPT SELECTION				
IRQ	JP1/D	JP1/E	JP1/F	JP1/G
í3	Closed	Open	Open	Open
4	Open	Closed	Open	Open
5	Open	Open	Closed	Open

Continued next page...

## THE NETWORK INTERFACE CARD TECHNICAL GUIDE GVC TECHNOLOGIES, INC. 8-BIT THREE-IN-ONE

. . . continued from previous page.

	CABLE TYPE SELECTION	
Cable Type	JP2/A	JP2/B
Unshielded Twisted Pair	Pins 2 & 3 closed	Pins 2 & 3 closed
AUI Transceiver via DB-15 port	Pins 2 & 3 closed	Pins 1 & 2 closed
í RG58A/U 50ohm coaxial	Pins 1 & 2 closed	Pins 1 & 2 closed

LINK TEST CONFIGURATION		
Setting	JP3	
í Enabled	Pins 1 & 2 closed	
Disabled	Pins 2 & 3 closed	

DIAGNOSTIC LED(S)			
LED	Color	Status	Condition
LED1	Green/Red	On	Data is not being transmitted/received
LED1	Green/Red	Off	Data is being transmitted/received
LED2	Green	On	10Base-T network connection is good
LED2	Green	Off	10Base-T network connection is broken or JP2/B is disabled