
## AST RESEARCH, INC. G-11 SIX PAK 286

Card Type Chipset Controller I/O Options Maximum Dram Memory Expansion Unidentified Feature Connector 4MB



CONNECTIONS				
Purpose	Location			
Feature Connector	CN1			

PARITY SELECT			
Setting	JP2		
Enable	Closed		
Disable	Open		

DRAM CONFIGURATION				
Size	Bank (	Bank <sup>r</sup>		
512KB	(2) 256K x 9	NONE		
1024KB	(2) 256K x 9	(2) 256K x 9		
2048KB	(2) 1M x 9	NONE		
4096KB	(2) 1M x 9	(2) 1M x 9		

Continued on next page. . .

## AST RESEARCH, INC. G-11 SIX PAK 286

. . .continued from previous page

DEFAULT CONFIGURATION TOGGLE				
Purpose	JP3			
Configuration default toggle first position Pins 2 & 3 closed				
Configuration default toggle second position	Pins 1 & 2 closed			
Note: This toggle functions as a clearing of the firmware on the board. If the jumper is first on Pins 2 & 3 then changing this jumper to Pins 1 & 2 will cause the firmware to be erased and default values to be loaded. This will then stay until the jumper is moved again.				

			DRAM SELECT			
Size	JP1/A	JP1/B	JP1/C	JP1/D	JP1/E	JP1/F
512KB	Pins 1 & 2	Pins 1 & 2	Pins 1 & 2	Pins 1 & 2	Pins 1 & 2	Pins 1 & 2
1024KB	Pins 1 & 2	Pins 1 & 2	Pins 1 & 2	Pins 1 & 2	Pins 1 & 2	Pins 1 & 2
2048KB	Pins 2 & 3	Pins 2 & 3	Pins 2 & 3	Pins 2 & 3	Pins 2 & 3	Pins 2 & 3
4096KB	Pins 2 &3	Pins 2 & 3	Pins 2 & 3	Pins 2 & 3	Pins 2 & 3	Pins 2 & 3
Note: Pins designated shown are in the closed position						

		BOARD NUMBER		
<sup>o</sup> urpose	JP4/A	JP4/B	JP4/C	JP4/D
Board number 1	Closed	Open	Open	Open
Board number 2	Open	Closed	Open	Open
Board number 3	Open	Open	Closed	Open
Board number 4	Open	Open	Open	Closed